

EKU12266 96 Tests General species Spermidine (SMD) CLIA Kit Organism Species: Pan-species(General)

FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC PROCEDURES.

# **INSTRUCTION MANUAL**

This manual may be updated as a result of continuous improvements. Please always refer to the hard copy manual included in the kit for your experiment.

Biomatik has been trusted by 10,000+ scientists since 2002. View thousands of publications citing Biomatik's fine products at <u>Google Scholar</u>



EKU12266 96 Tests General species Spermidine (SMD) CLIA Kit Organism Species: Pan-species(General)

FOR RESEARCH USE ONLY
NOT FOR USE IN DIAGNOSTIC PROCEDURES

This manual may be updated as a result of continuous improvements. Please refer to the hard copy manual included in the kit for your experiment.

Dec,2023

### [ INTENDED USE ]

The Chemiluminescent Immunoassay kit is designed for the in vitro sensitive quantitative measurement of spermidine in serum, plasma, tissue homogenates, cell lysates, cell culture supernates and other biological fluids.

### [ REAGENTS AND MATERIALS PROVIDED ]

Reagents	Quantity	Reagents	Quantity
Pre-coated, ready to use 96-well strip plate	1	Plate sealer for 96 wells	4
Standard	2	Standard Diluent	1×20mL
Detection Reagent A	1×120µL	Assay Diluent A	1×12mL
Detection Reagent B	1×120µL	Assay Diluent B	1×12mL
Substrate A	1×10mL	Substrate B	1×2mL
Wash Buffer (30 × concentrate)	1×20mL	Instruction manual	1

#### [ MATERIALS REQUIRED BUT NOT SUPPLIED ]

- 1. Luminometer capable of reading 96-well microplates with the following parameters: lag time 30.0secs; read time 1.0 sec/well .
- 2. Single or multi-channel pipettes with high precision and disposable tips.
- 3. Microcentrifuge Tubes.
- 4. Deionized or distilled water.
- 5. Absorbent paper for blotting the microplate.
- 6. Container for Wash Solution.
- 7. 0.01mol/L (or 1x) Phosphate Buffered Saline(PBS), pH7.0-7.2.

## [STORAGE OF THE KITS]

- For unopened kit: All the reagents should be kept according to the labels on vials. The Standard, Detection Reagent A, Detection Reagent B and the 96-well strip plate should be stored at -20°C upon receipt while the others should be at 4°C.
- 2. For opened kit: When the kit is opened, the remaining reagents still need to be stored according to the above storage condition. Besides, please return the unused wells to the foil pouch containing the desiccant pack, and reseal along entire edge of zip-seal.



#### Note:

It is highly recommended to use the remaining reagents within 1 month provided this is prior to the expiration date of the kit. For the expiration date of the kit, please refer to the label on the kit box. All components are stable up to the expiration date.

### [ SAMPLE COLLECTION AND STORAGE ]

**Serum** - Use a serum separator tube and allow samples to clot for two hours at room temperature or overnight at 4°C before centrifugation for 20 minutes at approximately 1,000×g. Assay freshly prepared serum immediately or store samples in aliquot at -20°C or -80°C for later use. Avoid repeated freeze/thaw cycles.

**Plasma** - Collect plasma using EDTA or heparin as an anticoagulant. Centrifuge samples for 15 minutes at 1,000×g at 2-8°C within 30 minutes of collection. Remove plasma and assay immediately or store samples in aliquot at -20°C or -80°C for later use. Avoid repeated freeze/thaw cycles.

**Tissue homogenates -** The preparation of tissue homogenates will vary depending upon tissue type.

- 1. Tissues were rinsed in ice-cold PBS to remove excess blood thoroughly and weighed before homogenization.
- 2. Minced the tissues to small pieces and homogenized them in fresh lysis buffer (catalog: IS007, different lysis buffer needs to be chosen based on subcellular location of the target protein) (w:v = 1:20-1:50, e.g. 1mL lysis buffer is added in 20-50mg tissue sample) with a glass homogenizer on ice (Micro Tissue Grinders woks, too).
- 3. The resulting suspension was sonicated with an ultrasonic cell disrupter till the solution is clarified.
- 4. Then, the homogenates were centrifuged for 5 minutes at 10,000×g. Collect the supernates and assay immediately or aliquot and store at ≤-20°C.

Cell Lysates - Cells need to be lysed before assaying according to the following directions.

- 1. Adherent cells should be washed by cold PBS gently, and then detached with trypsin, and collected by centrifugation at 1,000×g for 5 minutes (suspension cells can be collected by centrifugation directly).
- 2. Wash cells three times in cold PBS.
- 3. Resuspend cells in fresh lysis buffer with concentration of 10<sup>7</sup> cells/mL. If it is necessary, the cells could be subjected to ultrasonication till the solution is clarified.
- 4. Centrifuge at 1,500×g for 10 minutes at 2-8°C to remove cellular debris. Assay immediately or aliquot and store at ≤-20°C.
- **Cell culture supernates and other biological fluids** Centrifuge samples for 20 minutes at 1,000×g. Collect the supernates and assay immediately or store samples in aliquot at -20°C or -80°C for later use. Avoid repeated freeze/thaw cycles.


#### Note:

- Samples to be used within 5 days may be stored at 4°C, otherwise samples must be stored at -20°C (≤ 1 month) or -80°C (≤2 months) to avoid loss of bioactivity and contamination.
- 2. Sample hemolysis will influence the result, so hemolytic specimen should not be used.
- 3. When performing the assay, bring samples to room temperature.
- 4. It is highly recommended to use serum instead of plasma for the detection based on quantity of our in-house data.



### [ REAGENT PREPARATION ]

- 1. Bring all kit components and samples to room temperature (18-25°C) before use. If the kit will not be used up in one time, please only take out strips and reagents for present experiment, and leave the remaining strips and reagents in required condition.
- 2. **Standard -** Reconstitute the **Standard** with 0.5mL of **Standard Diluent**, kept for 10 minutes at room temperature, shake gently(not to foam). The concentration of the standard in the stock solution is 200,000pg/mL. Please prepare 5 tubes containing 0.6mL Standard Diluent and produce a quadruple dilution series according to the picture shown below. Mix each tube thoroughly before the next transfer. Set up 5 points of diluted standard such as 200,000pg/mL, 50,000pg/mL, 12,500pg/mL, 3125pg/mL, 781.25pg/mL, and the last EP tubes with **Standard Diluent** is the blank as 0pg/mL.



- 3. **Detection Reagent A and Detection Reagent B -** Briefly spin or centrifuge the stock Detection A and Detection B before use. Dilute them to the working concentration 100-fold with **Assay Diluent A** and **B**, respectively.
- 4. **Wash Solution** Dilute 20mL of Wash Solution concentrate (30x) with 580mL of deionized or distilled water to prepare 600mL of Wash Solution (1x).
- 5. **Substrate working Solution -** Mix the substrate A and B by the ratio of 99:1 to make the substrate working solution. Mix thoroughly. For example, prepare 1,000μL Substrate working Solution with 990μL Substrate A + 10μL Substrate B.

#### Note:

- 1. Making serial dilution in the wells directly is not permitted.
- 2. Prepare standard within 15 minutes before assay. Please do not dissolve the reagents at 37°C directly.
- 3. Please carefully reconstitute Standards or working Detection Reagent A and B according to the instruction, and avoid foaming and mix gently until the crystals are completely dissolved. To minimize imprecision caused by pipetting, use small volumes and ensure that pipettors are calibrated. It is recommended to suck more than 10µL for once pipetting.
- 4. The reconstituted Standards, Detection Reagent A and Detection Reagent B can be used only once.
- 5. Prepare Substrate working Solution within 15 minutes before assay.
- 6. If crystals have formed in the Wash Solution concentrate (30x), warm to room temperature and mix gently until the crystals are completely dissolved.
- 7. Contaminated water or container for reagent preparation will influence the detection result.



### [ SAMPLE PREPARATION ]

- 1. We are only responsible for the kit itself, but not for the samples consumed during the assay. The user should calculate the possible amount of the samples used in the whole test. Please reserve sufficient samples in advance.
- Please predict the concentration before assaying. If values for these are not within the range of the standard curve, users must determine the optimal sample dilutions for their particular experiments. Sample should be diluted by PBS.
- 3. If the samples are not indicated in the manual, a preliminary experiment to determine the validity of the kit is necessary.
- Tissue or cell extraction samples prepared by chemical lysis buffer may cause unexpected CLIA results due
  to the impacts of certain chemicals.
- 5. Due to the possibility of mismatching between antigen from other origin and antibody used in our kits (e.g., antibody targets conformational epitope rather than linear epitope), some native or recombinant proteins from other manufacturers may not be recognized by our products.
- 6. Influenced by the factors including cell viability, cell number or sampling time, samples from cell culture supernates may not be detected by the kit.
- 7. Fresh samples without long time storage is recommended for the test. Otherwise, protein degradation and denaturalization may occur in those samples and finally lead to wrong results.

## [ ASSAY PROCEDURE ]

- 1. Determine wells for diluted standard, blank and sample. Prepare 5 wells for standard points, 1 well for blank. Add 50µL each of dilutions of standard (read Reagent Preparation), blank and samples into the appropriate wells, respectively. And then add 50µL of **Detection Reagent A** to each well immediately. Shake the plate gently (using a microplate shaker is recommended). Cover with a Plate sealer. Incubate for 1 hour at 37°C. Detection Reagent A may appear cloudy. Warm to room temperature and mix gently until solution appears uniform.
- 2. Aspirate the solution and wash with 350µL of 1X Wash Solution to each well using a squirt bottle, multichannel pipette, manifold dispenser or autowasher, and let it sit for 1-2 minutes. Remove the remaining liquid from all wells completely by snapping the plate onto absorbent paper. Repeat 3 times. After the last wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against absorbent paper.
- 3. Add 100µL of **Detection Reagent B** working solution to each well, cover the wells with the plate sealer and incubate for 30 minutes at 37°C.
- 4. Repeat the aspiration/wash process for total 5 times as conducted in step 2.
- 5. Add 100μL of **Substrate working Solution** to each well. Cover with a new Plate sealer and incubate for 10 minutes at 37°C.
- 6. Measure the chemiluminescence signal in a microplate luminometer or as appropriate for the instrument used.

#### Note:

 Assay preparation: Keep appropriate numbers of wells for each experiment and remove extra wells from microplate. Rest wells should be resealed and stored at -20°C.



- 2. Samples or reagents addition: Please use the freshly prepared Standard. Please carefully add samples to wells and mix gently to avoid foaming. Do not touch the well wall. For each step in the procedure, total dispensing time for addition of reagents or samples to the assay plate should not exceed 10 minutes. This will ensure equal elapsed time for each pipetting step, without interruption. Duplication of all standards and specimens, although not required, is recommended. To avoid cross-contamination, change pipette tips between additions of standards, samples, and reagents. Also, use separated reservoirs for each reagent.
- 3. Incubation: To ensure accurate results, proper adhesion of plate sealers during incubation steps is necessary. Do not allow wells to sit uncovered for extended periods between incubation steps. Once reagents are added to the well strips, DO NOT let the strips DRY at any time during the assay. Incubation time and temperature must be controlled.
- 4. **Washing:** The wash procedure is critical. Complete removal of liquid at each step is essential for good performance. After the last wash, remove any remaining Wash Solution by aspirating or decanting and remove any drop of water and fingerprint on the bottom of the plate. Insufficient washing will result in poor precision and false elevated absorbance reading.
- 5. For Substrate A and B, please protect it from light.
- 6. Relative light units (RLUs) may differ from different luminometers. The Immunoassay was optimized using a Beijing Hamamatsu luminometer. Other instruments may require settings to be adjusted.

## [ TEST PRINCIPLE ]

The microplate provided in this kit has been pre-coated with a monoclonal antibody specific to spermidine. A competitive inhibition reaction is launched between biotin labeled spermidine and unlabeled spermidine (Standards or samples) with the pre-coated antibody specific to spermidine. After incubation the unbound conjugate is washed off. Next, avidin conjugated to Horseradish Peroxidase (HRP) is added to each microplate well and incubated. The amount of bound HRP conjugate is reverse proportional to the concentration of spermidine in the sample. Then the mixture of substrate A and B is added to generate glow light emission kinetics. Upon plate development, the intensity of the emitted light is reverse proportional to the spermidine level in the sample or standard.

## [ ASSAY PROCEDURE SUMMARY ]

- 1. Prepare all reagents, samples and standards;
- 2. Add  $50\mu L$  standard or sample to each well. And then add  $50\mu L$  prepared Detection Reagent A immediately.
  - Shake and mix. Incubate 1 hour at 37°C;
- 3. Aspirate and wash 3 times;
- 4. Add 100µL prepared Detection Reagent B. Incubate 30 minutes at 37°C;
- 5. Aspirate and wash 5 times;
- 6. Add 100µL Substrate Solution. Incubate 10 minutes at 37°C;
- 7. Read RLU value immediately.

## [ CALCULATION OF RESULTS ]


Average the duplicate readings for each standard, control, and samples. Create a standard curve on log-log graph paper, with the log of spermidine concentration on the y-axis and the RLU value on the x-axis. Draw the



best fit straight line through the standard points and it can be determined by regression analysis. Using some plot software, such as curve expert 1.30, is also recommended. If samples have been diluted, the concentration read from the standard curve must be multiplied by the dilution factor.

### [ TYPICAL DATA ]

In order to make the calculation easier, we plot the RLU value of the standard (X-axis) against the known log of concentration of the standard (Y-axis), although concentration is indeed the independent variable while RLU value is the dependent variable. The RLU values of the standard curve may vary according to the conditions of assay performance (e.g. operator, pipetting technique, washing technique or temperature effects). This curve is provided for demonstration only. Typical standard curve below is provided for reference only.



Typical Standard Curve for Spermidine CLIA.

### [ DETECTION RANGE ]

781.25-200,000pg/mL. The standard curve concentrations used for the CLIA's were 200,000pg/mL, 50,000pg/mL, 12,500pg/mL, 3125pg/mL, 781.25pg/mL.

## [ SENSITIVITY ]

The minimum detectable dose of spermidine is typically less than 284.75pg/mL.

The sensitivity of this assay, or Lower Limit of Detection (LLD) was defined as the lowest protein concentration that could be differentiated from zero. It was determined the mean RLU value of 20 replicates of the zero standard subtracted by their two standard deviations.

## [ SPECIFICITY ]

This assay has high sensitivity and excellent specificity for detection of spermidine.

No significant cross-reactivity or interference between spermidine and analogues was observed.

#### Note:

Limited by current skills and knowledge, it is impossible for us to complete the cross- reactivity detection between spermidine and all the analogues, therefore, cross reaction may still exist.



## [ RECOVERY ]

Matrices listed below were spiked with certain level of spermidine and the recovery rates were calculated by comparing the measured value to the expected amount of spermidine in samples.

Matrix	Recovery range (%)	Average(%)	
serum(n=5)	92-105	99	
EDTA plasma(n=5)	82-99	93	
heparin plasma(n=5)	80-96	88	

### [LINEARITY]

The linearity of the kit was assayed by testing samples spiked with appropriate concentration of spermidine and their serial dilutions. The results were demonstrated by the percentage of calculated concentration to the expected.

Sample	1: 2	1: 4	1: 8	1: 16
serum(n=5)	93-101%	97-108%	92-103%	89-99%
EDTA plasma(n=5)	88-105%	78-94%	91-102%	79-91%
heparin plasma(n=5)	80-93%	90-104%	86-96%	83-92%

### [ PRECISION ]

Intra-assay Precision (Precision within an assay): 3 samples with low, middle and high level spermidine were tested 20 times on one plate, respectively.

Inter-assay Precision (Precision between assays): 3 samples with low, middle and high level spermidine were tested on 3 different plates, 8 replicates in each plate.

CV(%) = SD/meanX100 Intra-Assay: CV<10% Inter-Assay: CV<12%

## [STABILITY]

The stability of CLIA kit is determined by the loss rate of activity. The loss rate of this kit is less than 5% within the expiration date under appropriate storage condition.

To minimize extra influence on the performance, operation procedures and lab conditions, especially room temperature, air humidity, incubator temperature should be strictly controlled. It is also strongly suggested that the whole assay is performed by the same operator from the beginning to the end.

## [ IMPORTANT NOTE ]

- Limited by the current conditions and scientific technology, we can't completely conduct the comprehensive identification and analysis on the raw material provided by suppliers. So there might be some qualitative and technical risks to use the kit.
- 2. The final experimental results will be closely related to validity of the products, so the kit should be used prior to the expiration date. And please store the kits exactly according to the instruction.



- Kits from different batches may be a little different in detection range, sensitivity and color developing time.
   Please perform the experiment exactly according to the instruction attached in kit while electronic ones from our website is only for reference.
- 4. Do not mix or substitute reagents from one kit lot to another. Use only the reagents supplied by manufacturer.
- 5. Protect all reagents from strong light during storage and incubation. All the bottle caps of reagents should be covered tightly to prevent the evaporation and contamination of microorganism. TMB Substrate should remain colorless till it is reacted with the enzyme which binds to the microplate.
- 6. There may be some foggy substance in the wells when the plate is opened at the first time. It will not have any effect on the final assay results. Do not remove microplate from the storage bag until needed.
- 7. Wrong operations during the reagents preparation and loading, as well as incorrect parameter setting for the plate reader may lead to incorrect results. It is recommended to use a single-mode luminometer or a multi-mode detection instrument set for luminescence measurement to measure light emission from 96-well microplates.
- 8. Variation in sample preparation and each step of experimental operation may cause different results. In order to get better reproducible results, the operation of each step in the assay should be controlled.
- 9. Each kit has been strictly passed Q.C test. However, results from end users might be inconsistent with our in-house data due to some unexpected transportation conditions or different lab equipments. Intra-assay variance among kits from different batches might arise from above factors, too.
- 10. Kits from different manufacturers with the same item might produce different results, since we haven't compared our products with other manufacturers.
- 11. The standard of the kit and immunogen used for antibody preparation are commonly recombinant proteins, as different fragments, expression systems, purification methods might be used in recombinant protein preparation, we can not guarantee the kit could detect recombinant protein from other companies. So, it is not recommended to use the kit for the detection of recombinant protein.
- 12. Please predict the concentration of target molecules in samples, or arrange a preliminary experiment, it is a good way to solve specific problem, e.g. the concentration of samples are beyond the detection range of the kit.
- 13. The kit might not be suitable for detection of samples from some special experiment, for instance, knock-out experiments, due to their uncertainty of effectiveness.
- 14. The instruction manual is also for the kit of 48T, but all reagents of 48T kit are reduced by half.
- 15. The kit is designed for research use only, we will not be responsible for any issue if the kit was used in clinical diagnostic or any other procedures.



## [TROUBLE SHOOTING]

Problem	Possible Source	Correction Action	
Poor	Improper standard curve preparation	Ensure accurate operation of the dilution	
Standard	Incomplete washing and aspiration	Adequate washing and adequate aspiration	
Curve	Inaccurate Pipetting	Check and Calibrate pipettes	
	Incomplete washing of wells	Ensure sufficient washing	
Poor	Inadequate mixing and aspiration reagents	Adequate aspiration and mixing reagents	
Precision	Reused pipette tips, containers and sealers	Change and use new pipette tips, containers and sealers	
	Inaccurate Pipetting	Check and Calibrate pipettes	
	Inadequate reagent volumes added to wells	Calibrate pipettes and Add adequate reagents	
Low	Incorrect incubation times	Ensure sufficient incubation times	
RLU	Incorrect incubation temperature	Reagents balanced to room temperature	
Values	Conjugate or substrate reagent failure	Mix conjugate & substrate, color should develop immediately	
	Improper Sample Storage	Store the sample properly and use the fresh sample	
Sample	Improper sample collection and preparation	Take proper sample collection and preparation method	
Values	Low quantity of analyte in samples	Use new sample and repeat assay	